




Important Handlebar Grip Replacement Supplement


! WARNING! Grips may loosen or fracture and may cause loss of control if the grips are not replaced!

Refer to the **tone** owner's manual that came with your product for complete warnings and instructions.

Parts Included



tone2 | tone3




Remove the EXISTING handlebar grips


- 1 Remove both existing grips (1a and 1b) by turning the left grip counter-clockwise and the right grip clockwise.
- 2 Remove both washers (2a and 2b).
- 3 Loosen the hex screws (3a and 3b) on both thumb levers.
- 4 Remove the thumb levers (4a and 4b) from the handlebar.

Note: Discard the washers, and existing grips, they are no longer needed.

View from underside of the handlebars



After





Attach the NEW handlebar grips

- 1 Slide the new clamps (1a and 1b) onto each side of the handlebar.
- 2 Route the wires (2a and 2b) into each clamp slot.
- 3 Slide the thumb levers (3a and 3b) onto each side of the grips.
- 4 Insert the new grips (4a and 4b) completely through the thumb levers and clamps.

Rotate the left grip clockwise and the right grip counter-clockwise until fully tightened.

- 5 Confirm the L and R sticker (5a and 5b) on the end of each new grip matches the correct side.
- 6 Tighten the hex screws (6a and 6b) on the clamps using the 4 mm hex key.
- 7 Tighten the hex screws (7a and 7b) on the thumb levers using the 3 mm hex key.




tone1



Note: Discard the washers, and existing grips, they are no longer needed.

Remove the EXISTING handlebar grips

- 1 Remove both existing grips (1a and 1b) by turning the left grip clockwise, and the right grip counter-clockwise.
- 2 Remove both washers (2a and 2b).
- 3 Loosen the hex screw on the thumb lever and remove the thumb lever.
- 4 Loosen the hex screw on the hand brake and remove the hand brake.



Attach the NEW handlebar grips

- 1 Slide the new clamps (1a and 1b) onto each side of the handlebar until it meets the center control panel.
- 2 Route the wire into the clamp slot.
- 3 Slide the thumb lever onto the right-hand grip until it meets the clamp.
- 4 Slide the hand brake onto the left-hand grip until it meets the clamp.
- 5 Insert the new grips (5a and 5b) completely through the brake and clamps. Rotate the left grip clockwise and the right grip counter-clockwise until fully tightened.
- 6 Confirm the L and R sticker (6a and 6b) on the end of each new grip matches the correct side.
- 7 Tighten the hex screws (7a and 7b) on the clamps using the 4 mm hex key.
- 8 Tighten the hex screw in the thumb levers using the 3 mm hex key.
- 9 Tighten the hex screw in the hand brake using the 5 mm hex key.